

Table 1		
Inspection Type Name - Added	Counting Category	PCS Inspection Type Code
CSO Sampling	Sampling	#
CSO Non-Sampling	Non-Sampling	\$
SSO Sampling	Sampling	+
SSO Non-Sampling	Non-Sampling	&
CAFO Sampling	Sampling	\
CAFO Non-Sampling	Non-Sampling	=
Stormwater (Construction) Sampling	Sampling	{
Stormwater (Construction) Non-Sampling	Non-Sampling	}
Stormwater (Non-Construction) Sampling	Sampling	:
Stormwater (Non-Construction) Non-Sampling	Non-Sampling	~
Stormwater (MS4) Sampling	Sampling	<
Stormwater (MS4) Non-Sampling	Non-Sampling	-
Stormwater (MS4) Audit	Audit	>

The new PCS inspection types in Table 1 replace the following five existing wet weather inspection types, which are being inactivated for regions only. As indicated above, states may still use the “old” wet weather codes until the state is brought into ICIS-NPDES.

Table 2	
Inspection Type Name - Inactivated	PCS Inspection
CSO	Y
SSO	V
CAFO	K
Stormwater	W
MS4	9

